

Please take extreme care when installing this light — once the roof liner is cut, there's no going back.

The ideal mounting spot is just behind the front seats, roughly in line with the rear grab handles (see image below). This position avoids the roof cross beams.



After placing the template on the roof liner, use the supplied needle to carefully trace around the outer edge. If the needle passes through cleanly, you're clear of any structural members.

You can also peel back the door rubber seal and peek between the roof and liner to spot any cross beams. Stick to the recommended area — don't move the template further back in the vehicle.